

The Audality M1 Wireless Guitar System

The Audality M1 is a Pro-level Wireless Guitar System built with WiC® wireless technology. It delivers a high-fidelity wireless instrument connection with sound quality that rivals the highest quality cables available. Plug the M1 transmitter with the blue label into your instrument and plug the longer cable from the receiver with the red label to your amplifier, pedal, or mixing board. Works with both guitar, bass (passive and active pickups) and almost any other instrument with a line level output.



Add Unlimited Transmitters

If you change out guitars mid-song, you'll love the M1's ability to swap instantly between transmitters. You can pair as many M1 transmitters to your receiver, and the receiver remembers all of your transmitters. When it's time to change guitars just turn off the transmitter, pick up your new guitar, and turn it on.



Record and Edit without Cables or Power

The M1 is the first wireless guitar system the lets you play right into your editing system with the same transmitter you use to play live. Just plug the receiver (sold separately) into your computer's USB port, set your DAW software to use it as your sound card, and start playing.



Exceptional Tone.

We've been told that the M1 sounds as good as the highest quality cables available. We worked hard to get flat frequency response from 1 Hz to 22kHz - well below audible on both the low end and the high end. That means it captures alternate tunings on the bass, full harmonics on guitar, and even synthesized frequencies in electronic music.

Automatic Channel Selection with Instant Pairing.

We engineered the simplest channel selection and pairing available. One-touch pairing makes it easy to change receivers, and you NEVER have to tell it what channel to use because it has a built-in spectrum analyzer that automatically finds the best channel available.

Superior Connectivity

The M1 has a frequency hopping radio that automatically and seamlessly finds the best channel available.

Extra Long Battery Life

The M1 runs for about 8 hours on a charge, and it charges in under 3 hours, so you can gig all weekend on a single charge.

USB Receiver Accessory

The USB Receiver works with Windows and MacOS, and works well with a number of DAW suites: ProTools, Audacity, and others.

SPECIFICATIONS

System Description	M1 Wireless Guitar System
Frequency Response	1 Hz-22kHz
Wireless Operation	2.4 GHz uncompressed digital audio with frequency channel hopping
Range	Up to 500 feet
Audio Encoding	High resolution 24-bit/48 kHz audio
Pairing	Simple, one-touch pairing
Radio Channel	Automatic Channel Selection
Batteries	Long-lasting rechargeable batteries
Cables	¼" instrument cables
Weight	2 ounces (50g.)
L x W x H	Transmitter: 3-7/8" (99mm) x 2-1/8" (54mm) x 7/8" (21mm) Receiver: 3-7/8" (99mm) x 2-1/8" (54mm) x 7/8" (21mm) USB Receiver (sold separately): 2-7/8 (73mm) x 1" (25mm) x .5" (12mm)
Included Accessories	Transmitter Cable (1/4" straight to right angle, .5m length) Receiver Cable (1/4" straight to straight, 2 m length) Wall Charger (USB) USB charging cables (2)

